


HYDRONIC II C

**Technical description, installation,
operating and maintenance instructions.**



Heater for diesel fuel

Hydronic II C

D 5 S – 12 V

D 5 S – 24 V

Order No.

25 2506 05 00 00

25 2507 05 00 00

**Water heater for diesel fuel
operating independently of an engine.**



Eberspächer

A world of comfort

1 Introduction

Contents

Chapter	Chapter title	Chapter contents	Page
1	Introduction	<ul style="list-style-type: none"> • Contents 2 • Concept of this manual 3 • Special text structure, presentation and picture symbols 4 • Important information before starting work 4 • Statutory regulations 5, 6 • Safety instructions for installation and operation 7 • Accident prevention 7 	
2	Product information	<ul style="list-style-type: none"> • Heater scope of supply 8, 9 • Technical data 10 • Main heater dimensions 11 • Main dimensions of water pump, 12 volt 11 • Main dimensions of water pump, 24 volt 11 	
3	Installation	<ul style="list-style-type: none"> • Installation location 12 • Permissible installation positions / heater and water pump 13 • Installation and fixing water pump – 12 volt 14 • Installation and fixing water pump – 24 volt 15 • Nameplate 15 • Installation and fixing – heater 16 • Fix fuse holder and relay socket 17 • Connection to the cooling water circuit 17 – 20 • Exhaust system 21 • Combustion air system 22 • Fuel supply 23 – 27 	
4	Operation and function	<ul style="list-style-type: none"> • Operating instructions 28 • Important instructions for operation 28 <ul style="list-style-type: none"> – Initial commissioning 28 – Safety checks before starting up the heater 28 – Before switching on 28 • Functional description 28 <ul style="list-style-type: none"> – Switch on parking heater mode 28 – Heating mode 28 – Heating mode at altitudes 29 • Control and safety devices 29 • Emergency shutdown "EMERGENCY OFF" 29 	
5	Electrical system	<ul style="list-style-type: none"> • Heater wiring 30 • Heater wiring / parts list 30 • Circuit diagrams 31 – 40 	
6	Troubleshooting Maintenance Service	<ul style="list-style-type: none"> • If any faults occur, please check the following items 41 • Troubleshooting 41 • Maintenance instructions 41 • Service 41 	
7	Environment	<ul style="list-style-type: none"> • Certification 42 • Disposal 42 • EU Declaration of Conformity 42 • UKCA Declaration of Conformity 42 	
8	List	<ul style="list-style-type: none"> • List of abbreviations 43 	



1 Introduction

Concept of this manual

This manual aims to support the service company installing the heater and to provide the user with all important information about the heater. The manual has been divided into 8 chapters to make it easier to find the corresponding information quickly.

1 Introduction
Here you find important introductory information about installation of the heater and about the structure of the manual.

2 Product information
Here you will find information about the scope of supply, the technical data and the dimensions of the heater.

3 Installation
Here you will find important information and instructions referring to installation of the heater.

4 Operation and function
Here you will find information about the operation and function of the heater.

Electrical system
Here you will find information about the electronic system

5 and electronic components of the heater.

6 Troubleshooting / maintenance / service
Here you will find information on possible faults, maintenance and technical support.

7 Environment
Here you will find information about certification and disposal of the heater together with the EU Declaration of Conformity.

8 List
Here you will find the list of abbreviations.

1 Introduction

Special text structure, presentation and picture symbols

This manual uses special text structures and picture symbols to emphasize different contents.

Please refer to the following examples for their meanings and appropriate action.

Special text formats and presentations

A dot (•) indicates a list which is started by a heading.

If an indented dash (–) follows a dot, this list is subordinate to the dot.

Picture symbols



Regulation!

This picture symbol with the remark "Regulation!" refers to a statutory regulation.

Failure to comply with this regulation results in expiry of the type-approval for the heater and preclusion of any guarantee and liability claims on Eberspächer Climate Control Systems GmbH.



Danger!

This picture symbol with the remark "Danger!" refers to the risk of a fatal danger to life and limb.

Under certain circumstances, failure to comply with these instructions can result in severe or life-threatening injuries.



Caution!

This picture symbol with the remark "Caution" refers to a dangerous situation for a person and / or the product.

Failure to comply with these instructions can result in injuries to people and / or damage to machinery.

Please note!

These remarks contain recommendations for use and useful tips for installation of the heater.

Important information before starting work

Range of application of the heater

The heater is intended for installation in the following vehicles:

- All kinds of vehicles
- Construction machinery
- Agricultural machinery
- Boats, ships and yachts

Please note!

The heater can be installed in vehicles used for the transport of dangerous goods according to ADR.

Intended purpose of the heater (via the vehicle's own heat exchanger)

- Pre-heating, de-misting windows
- Heating and keeping the following warm:
 - Driver and working cabs
 - Freight compartments
 - Ship's cabins
 - Passenger and crew compartments
 - Vehicle engines and units

On account of its functional purpose, the heater is **not** permitted for the following applications:

- Long-term continuous operation, e.g. for pre-heating and heating of:
 - Residential rooms
 - Garages
 - Work huts, weekend homes and hunting lodges
 - Houseboats, etc.



Caution!

Safety instructions for the range of application and proper, intended use!


The heater must only be used and operated for the range of application stated by the manufacturer in compliance with the "Operation instructions" included with every heater.



1 Introduction

Statutory regulations

The Federal Motor Transport Authority has issued an "EC type approval", "EMC type-approval" and the approval for a component according to ECE R122 and ECE-R10 for the heater for installation in motor vehicles with the following official type-approval marks, noted on the heater name plate.

Heater type:	ECE type approval mark:
Hydronic II C	 122 R – 000274 10 R – 045887



Regulations!

Excerpt from ECE regulation No. 122 of the European Parliament and the Council

General regulations

- **Operating state display**
 - A clearly visible operating display in the user's field of vision must indicate when the heater is switched on and off.

Regulations concerning installation in the vehicle

- **Scope**
 - Subject to differing stipulations in the following section, combustion heaters must be installed according to the regulations 5.3 of ECE-R122.
 - It is assumed that Class O vehicles with heaters for liquid fuel conform to the regulations 5.3 of ECE-R122.
- **Position of the heater**
 - Parts of the structure and other components near the heater must be protected from excessive heat exposure and possible fuel or oil contamination.
 - The heater must not pose a fire hazard even when it overheats. This requirement is deemed to be fulfilled if adequate clearance is ensured for all parts during installation, sufficient ventilation is provided and fireproof materials or heat shields are used.
 - The heater must not be mounted in the passenger compartment of vehicles in class M₂ and M₃. However, a heater in a hermetically sealed enclosure which also complies with the aforementioned conditions may be used.
 - The factory nameplate or duplicate of it must be affixed so that it can still be easily read when the heater is installed in the vehicle.
 - All appropriate precautions must be taken when arranging the heater to minimise the risk of injuries to persons or damage to other property.
- **Fuel supply**
 - The fuel intake connection must not be located in the passenger compartment and must be sealed with a properly closing lid to prevent any fuel leaks.

- In heaters for liquid fuel where the heater fuel is separate from the vehicle fuel, the type of fuel and intake connection must be clearly identified.
- A warning sign is to be fixed to the intake connection indicating that the heater must be switched off before refuelling.

- **Exhaust system**

- The exhaust outlet must be arranged so as to prevent any penetration of exhaust fumes into the vehicle interior through the ventilation system, warm air intakes or open windows.

- **Combustion air intake**

- The air for the heater's combustion chamber must not be sucked in from the vehicle's passenger compartment.
- The air intake must be arranged or protected in such a way that it cannot be blocked by other objects.

- **Automatic control of the heating system**

- If the engine fails, the heating system must be automatically switched off and the fuel supply stopped within 5 seconds. The heater may remain in operation if a manual device has already been activated.

Please note!

The heater is **not** approved for installation in the driver's cab or passenger compartment of Class M₁ vehicles (vehicles for passenger transport / cars) and N vehicles (vehicles for the transport of goods).

1 Introduction

Statutory regulations



Regulations!

Additional regulations for certain vehicles named in Directive 94/55/EC of the ADR Agreement

Scope

The annex applies to vehicles to which the special provisions of Directive 94/55/EC of the ADR Agreement for combustion heaters and their installation apply.

Definition of terms

The vehicle designations "EX / II", "EX / III", "AT", "FL" and "OX" according to Chapter 9.1 of the ADR Agreement Directive are used for the purposes of this annex.

Technical specifications

General regulations (vehicles EX / II, EX / III, AT, FL and OX)

Avoid heating and ignition

Combustion heaters and their exhaust pipes must be designed, arranged, protected or covered to avoid any unacceptable risk of heating or ignition of the load. This requirement is met if the fuel tank and the exhaust system of the heater comply with the requirements described in the "fuel tank" and "exhaust system and exhaust pipe layout" sections. Compliance with these requirements must be checked on the complete vehicle.

Fuel tank

Fuel tanks for supply of the heater must conform to the following regulations:

- In the event of a leakage, the fuel must be drained to the floor without coming into contact with any hot vehicle parts or the vehicle's load;
- Fuel tanks which contain petrol must be equipped with a flame arrester or hermetically sealed cap at the filler neck.

Exhaust system and exhaust pipe layout

The exhaust system and the exhaust pipes must be laid or protected so that dangerous heating or ignition of the vehicle's load cannot occur. Parts of the exhaust system located directly under the fuel tank (diesel fuel) must be positioned at a distance of at least 100 mm from the tank or be protected by a heat shield.

Switch on combustion heater

The combustion heater may only be switched on manually! Automatic switching on via a programmable switch is not allowed.

EX / II and EX / III vehicles

Combustion heaters for gaseous fuel are not allowed.

FL vehicles

Combustion heaters must at least be able to be taken out of service by the procedures named in the following:

- a) Switching off manually in the driver's cab
- b) Shutdown of the vehicle's engine; in this case the heater may be switched back on manually by the vehicle driver;
- c) Starting up an installed fuel pump in the vehicle for transported dangerous goods.

After running of the combustion heater

After running of the switched off combustion heater is permitted. In the cases named in the "FL vehicles" section under letters b) and c), the supply of combustion air must be interrupted by suitable means following an after-running period of 40 seconds maximum. Only combustion heaters whose heat exchangers are verifiably not damaged by the reduced after-running time of 40 seconds beyond their usual operating period may be used.

Please note!

- Compliance with the statutory regulations, the additional regulations and the safety instructions is prerequisite for guarantee and liability claims.
Failure to comply with the statutory regulations and safety instructions and incorrect repairs, even if original spare parts are used, make the guarantee null and void and preclude any liability for Eberspächer Climate Control Systems GmbH.
- Subsequent installation of this heater must comply with these installation instructions.
- The statutory regulations are binding and must also be observed in countries which do not have any special regulations.
- When installing the heater in vehicles not subject to the German Road Traffic Licensing Regulations (StVZO), for example ships, the respective specially valid regulations and installation instructions must be observed.
- Installation of the heater in special vehicles must comply with the regulations applying to such vehicles.
- Other installation requirements are given in the relevant sections of this manual.



1 Introduction

Safety instructions for installation and operation



Danger!

Risk of injury, fire and poisoning!

- Disconnect the vehicle battery before starting any kind of work.
- Before working on the heater, switch the heater off and let all hot parts cool down.
- The heater must not be operated in closed rooms, e.g. in the garage or in a multi-storey car park.



Caution!

Safety instructions for installation and operation!

- The heater must only be installed by a JE partner authorised by the manufacturer according to the instructions in this manual and possibly according to special installation recommendations; the same applies to any repairs to be carried out in the case of repairs or guarantee claims.
- Repairs by non-authorised third-parties or with not original spare parts are dangerous and therefore not allowed. They result in expiry of the type-approval of the heater; consequently, when installed in motor vehicles they can cause expiry of the vehicle operating licence.
- The following measures are not allowed:
 - Changes to components relevant to the heater.
 - Use of third-party components not approved by Eberspächer Climate Control Systems GmbH.
 - Installation or operation not conforming to the statutory regulations, safety instructions or specifications relevant for safe operation as stated in the installation instructions and operating instructions. This applies in particular to the electrical wiring, fuel supply, combustion air system and exhaust system.
- Only original accessories and original spare parts must be used during installation or repairs.
- Only control units approved by Eberspächer may be used to operate the heater.
Use of other control units can cause malfunctions.
- Before the heater is installed again in another vehicle, rinse the heater parts carrying water with clear water.
- When carrying out electric welding on the vehicle, the positive cable at the battery should be disconnected and placed at ground to protect the control box.
- Do **not** operate the heater anywhere where there are readily flammable materials (e.g. dry grass, leaves, paper, etc.) in the area of the exhaust system or where ignitable fumes and dust can form, e.g. near a
 - fuel depot
 - coal depot
 - wood depot
 - grain depots, etc.
- The heater must be switched off when refuelling.
- If the heater is fitted in a safety casing, etc., the heater's installation box must not be used as storage space and must be kept clear.
In particular fuel canisters, oil cans, spray cans, gas cartridges, fire extinguishers, cleaning rags, items of clothing, paper etc. must not be stored or transported on or next to the heater.
- Defect fuses must only be replaced by fuses with the prescribed rating.
- If fuel leaks from the heater fuel system, arrange for the damage to be repaired immediately by a JE service partner.
- When topping up cooling water, only use coolants approved by the vehicle manufacturer; please refer to the vehicle's operating manual.
Blending with coolants not approved for use can cause damage to the engine and heater.
- The after-running of the heater must not be prematurely interrupted, e.g. by pressing the battery disconnecter, except for an emergency stop.

Accident prevention

General accident prevention regulations and the corresponding workshop and operating safety instructions are to be observed.

2 Product information

Order No. and scope of supply

Diesel heaters

Quantity / Designation	Order no.
1 Hydronic II C – 12 volt	25 2506 05 00 00
1 Hydronic II C – 24 volt	25 2507 05 00 00

Heater scope of supply – see Fig. page 9

Figure No.	Designation
1	Heater
2	Metering pump
3	Water pump, 12 volt
4	Bracket, water pump
5	Water pump cable harness, 2 m long
6	Water pump, 24 volt
7	Bracket, water pump
8	Water pump cable harness
–	Connection parts, electrical
–	CD – Technical documentation

To be ordered separately (applies to all heaters):

1	Control unit**	----
1	Universal installation kit	25 2506 80 00 00
1	Universal installation kit if using EasyStart Timer, Remote, Remote+ or Select	25 2506 83 00 00

* For details of control units, please refer to the price list or product information.

Installation kit scope of supply

Figure No.	Designation
9	Exhaust silencer
10	Cable loom, heater
11	Bracket, heater
12	Water hose
13	Flexible exhaust pipe, 900 mm long
14	Flexible exhaust pipe end, 300 mm long
15	Z-bracket, exhaust silencer
16	L-bracket, exhaust silencer
17	Bracket, metering pump
18	Combustion air hose, 760 mm long
19	Pulse damper
20	Universal water hose
21	Pipe, 4 x 1, transparent
22	Adapter, Ø 7.5 / 3.5
23	Combined bracket
24	Lead harness, blower
25	Relay for blower
26	Lead harness, metering pump
27	Fuel tank extractor
28	Screw, M6 x 17, thread-forming

Cable harnesses

A	Connection, control units
B	Plus supply connection, blower relay
C	Activation, vehicle blower
E	Connection to terminal 85 (1-pin, br)
F	Connection to terminal 86 (1-pin, rt/sw)
G	Diagnosis query plug connection


Please note!

- Parts without a figure no. are small parts and packed in a bag.
- Please refer to the production information if any other parts are required for the installation.
- The self-tapping screws included in the scope of supply can be used for a sheet metal thickness of 2 – 6 mm (tightening torque: 9⁺¹ Nm).



2 Product information

Scope of supply – heater and installation kit



2 Product information

Technical data for the diesel heater

Heater type	Hydronic II C					
Heater version	D 5 S					
Heating medium	Mixture of water and coolant (max. 50 % coolant)					
Fuel – see also "Fuel Quality" page 27	Diesel – standard commercially available (EN 590) Bio diesel fuel (FAME according to EN 14214)					
Rated voltage	12 volt			24 volt		
Control of the heat flow	Power	High	Low	Power	High	Low
Heat flow (watt)	4800	2100	1200	4800	2100	1200
Fuel consumption (l/h)	0.59	0.26	0.15	0.59	0.26	0.15
Average electrical power consumption (watt)						

Technical data for the water pump

Rated voltage	12 volt	24 volt
Electrical power consumption	< 12 watt	< 32 watt
Delivery rate	680 l/h	1,600 l/h
Delivery pressure difference	0.1 bar	0.1 bar



Caution!

Safety instructions for technical data!

Failure to comply with the technical data can result in malfunctions.


Please note!

If no limit values are given, the technical data listed is with the usual heater tolerances of $\pm 10\%$ at nominal voltage, 20 °C ambient temperature and Esslingen reference altitude.




2 Product information


Main heater dimensions



Main dimensions of water pump, 12 volt



Main dimensions of water pump, 24 volt



3 Installation

Installation location


The heater and the water pump are installed in the engine compartment.

The heater and the water pump must be installed below the min. cooling water level (header tank, radiator, vehicle's heat exchanger) so that the heat exchanger of the heater and water pump can independently vent.

Please note!


- Observe the regulations and safety instructions for this chapter, given on page 4 – 7.
 - The installation suggestions made in the installation instructions are just examples.
- Other installation locations are possible if they comply with the installation requirements stated in these installation instructions.
- Further installation information (e.g. for boats and ships) is available from the manufacturer on request.
 - Observe the tolerable installation position together with the operating and storage temperatures.
 - Ensure adequate distance from hot vehicle parts.
 - Do not install the water pump at the lowest point in the water circuit, as otherwise the particles in the water circuit settle in the water pump. A water filter must be used if the cooling water is highly soiled/contaminated with particles.

Installation example 12 volt heater in a van




- 1 Heater
- 2 Water pump
- 3 Exhaust pipe with exhaust silencer
- 4 Combustion air hose
- 5 Fuse bracket
- 6 Blower relay
- 7 Control unit
- 8 Metering pump
- 9 T-piece for fuel

Installation example 12 volt heater in a car



- 1 Heater
- 2 Water pump
- 3 Exhaust pipe with exhaust silencer
- 4 Combustion air hose
- 5 Blower relay
- 6 Fuse bracket
- 7 Control unit
- 8 Metering pump
- 9 Fuel tank extractor

Installation example 24 volt heater in a lorry



- 1 Heater
- 2 Water pump
- 3 Exhaust pipe with exhaust silencer
- 4 Combustion air hose
- 5 Fuse bracket
- 6 Blower relay
- 7 Control unit
- 8 Metering pump
- 9 Fuel tank extractor



3 Installation

Permissible installation positions

The heater and the water pump should preferably be installed in the normal position. Depending on the installation conditions, the heater can be installed within the permissible swivel ranges, see sketch.


In heating mode, the normal and maximum installation positions shown can differ by up to $+15^\circ$ in all directions for a short time.

These differences, caused by tilted positions of the vehicle, do not have any negative effects on the heater's function.

Please note!


Heater in normal position with permissible swivel ranges

Heater in horizontal installation position (normal position*) with permissible swivel range up to the vertical installation position. All installation positions between 0° and 90° are permitted.



Heater upright in horizontal installation position (normal position*) with permissible swivel range up to the horizontal installation position.

All installation positions between 0° and 90° are permitted.



Please note!

If a heater is swivelled out of the normal position, the fuel connections must **always** be at the bottom.

Water pump – 12 volt

The water pump can be installed in any position.


The water inlet must be designed so that it is always completely filled with water (the water pump is not self-priming).

Please note!

The installation position of the water pump with the pump head facing downwards is unfavourable for automatic venting.

Water pump – 24 volt

in normal position with permissible swivel ranges



3 Installation

Installation and fixing

Water pump – 12 volt

The water pump bracket included in the installation kit must be fixed to the heater using the self-threading screws M6 x 16 supplied (see installation examples below) or in a suitable position in the vehicle, depending on the installation conditions (tightening torque: 11⁺¹ Nm). Then insert the water pump in the rubber element and press in until

the water pump has latched into position.

Use the universal water hose included in the scope of supply to install the water pump on the heater and shorten the hose's length as necessary.

Use the hose clips to fix the water hose.



Please note!

If using the "water pump" cable loom supplied, new contacts must be attached, two single core seals and the connector housing must be installed.

Installation examples



The water pump is fixed to the "fuel connection" side of the heater with rising water inlet connection. The water discharge connection of the water pump faces upwards.

The water pump is fixed to the "water outlet connection" side of the heater with rising water inlet connection. The water discharge connection of the water pump faces upwards.



The water pump is fixed to the "fuel connection" side of the heater with the water inlet connection facing downwards. The water discharge connection of the water pump faces upwards.

The water pump is fixed to the "water discharge connection" side of the heater with the water inlet connection facing downwards. The water discharge connection of the water pump faces upwards.





3 Installation

Installation and fixing Water pump – 24 volt


Use the self-threading screw M6 x 25 supplied to fix the bracket for the water pump included in the installation kit directly onto the heater, or in a suitable position on the vehicle. (Tightening torque: 11^{+1} Nm). Then insert the water pump in the bracket. Use the universal water hose included in the scope of supply to in-

stall the water pump on the heater and shorten the hose's length as necessary.


Use the hose clips to fix the water hose.

Installation examples

The water pump is fixed directly to the "fuel connection" side of the heater with horizontal water inlet connection. The water discharge connection of the water pump faces upwards.



The water pump is fixed directly to the "water discharge connection" side of the heater with horizontal water inlet connection. The water discharge connection of the water pump faces upwards.



Please note!


Note the permitted installation positions of the water pump 24 V on page 13.

Nameplate

The nameplate is fastened to the water jacket of the heater. The second nameplate (duplicate) is detachable, and is attached to the side of the heater. If required, the duplicate nameplate can be adhered in a clearly visible position on the heater or near to the heater.

Please note!

Note and follow the regulations and safety instructions for this chapter content on page 5.



- 1 Nameplate
- 2 second nameplate (duplicate)

3 Installation



Installation and fixing – heater

Use the bracket included in the installation kit to fix the heater in a suitable position on the vehicle.

Installation steps



1. Use hexagon screws size M6 x 12 and hexagon nuts size M6 or self-tapping screws to fix the bracket.

Fixing with 3 screws or fixing with 4 screws.




2. Mount special screw M6 x 17 (self-threading) onto the heater.


Mount special screw M6 x 17 (self-threading) on heater on the fuel connection side (left-hand Fig.) or on the water discharge connection side (right-hand Fig.) (tightening torque: 11^{+1} Nm).



3. Hook heater into the bracket



4. Use 2 hexagon screws M6 x 16 (self-threading) to fix heater to the bracket (tightening torque: 11^{+1} Nm).






3 Installation

Fix fuse holder and relay socket

Use a hexagon screw size M6 x 12 and hexagon nut size M6 to fix the bracket in a suitable position within the vehicle's engine compartment. Fix the fuse holder to the bracket using 2 blind rivets 4 x 8; to do this, press in the bolts of the two blind rivets until the fuse holder sits securely on the bracket. Use a blind rivet 5.5 x 12 to fix the relay socket to the bracket; to do this, press in the bolt of the blind rivet until the relay socket sits securely on the bracket.



Connection to the cooling water circuit

The heater and the water pump are integrated in the cooling water circuit in the water flow hose from the vehicle engine to the heat exchanger. There are four installation options for this. The installation options are described on pages 18 – 20.



Danger!

Risk of injuries and burns!

The coolant and components of the coolant circuit get very hot.

- Parts conveying water must be routed and fastened in such a way that they pose no temperature risk to man, animals or material sensitive to temperature from radiation / direct contact.
- Before working on the cooling water circuit, switch the heater off and wait until all the components have cooled down completely, if necessary wear protective gloves.

Please note!

- When installing the heater and the water pump, please note the direction of flow of the cooling water circuit.
- Fill the heater and water hose with coolant before connecting to the coolant circuit.
- Route the water hoses without any kinks, and in a rising position if possible.
- When routing the water pipes, maintain sufficient clearance from hot vehicle parts.
- Protect all water hoses / water pipes from chafing and from extreme temperatures.
- Secure all hose connections with hose clips (tightening torque: $3^{+0.5}$ Nm).
- Re-tighten the hose clips after the vehicle has been running for 2 hours or has travelled 100 km.
- The minimum water flow rate is only guaranteed if the temperature difference of the heating medium does not exceed 10 K between water inlet and water outlet during heating.
- Only overpressure valves with an opening pressure of min. 0.4 – max. 2 bar may be used in the cooling water circuit.
- As corrosion protection the cooling water must contain at least 10 % coolant (anti-freeze).
- During cold periods the coolant water must contain sufficient coolant (antifreeze).
- Before commissioning the heater for the first time or after changing the cooling water, the whole cooling water circuit including the heater must be vented without bubbles according to the vehicle manufacturer's instructions.
- Only top up with coolant approved by the vehicle manufacturer.

3 Installation


Connection to the cooling water circuit

Integrate heater and water pump in the water flow hose from the vehicle engine to the heat exchanger; "inline connection"

Cut the water flow hose from the vehicle engine to the vehicle's heat exchanger.
Use connectors and water hoses to connect the heater and the water pump to the water flow hose.
Lay a water hose from the discharge end of the water pump to the water inlet socket of the heater and connect.

Heating characteristics

If the heater is switched on, the heat is initially fed via the heater's own heat exchanger to the vehicle's engine only.
After the cooling water has reached a temperature of approx. 30 °C – depends on the selected blower setting – the vehicle blower switches on and the heat is then also fed to the passenger compartment.



Integrate the heater, water pump and non-return valve in the cooling water circuit


Cut the water flow hose from the vehicle engine to the vehicle's heat exchanger and insert the non-return valve.
Use water hoses to connect the heater and the water pump to the non-return valve. Lay a water hose from the discharge end of the water pump to the water inlet socket of the heater and connect.

Heating characteristics

If the heater is switched on, the heat is initially fed via the heater's own heat exchanger to the vehicle's engine only.
After the cooling water has reached a temperature of approx. 30 °C – depends on the selected blower setting – the vehicle blower switches on and the heat is then also fed to the passenger compartment.

Advantage of the "inline connection" water circuit

No loss of vehicle heating effectiveness if heater is switched off.



Please note!

Non-return valve must be ordered separately, please refer to the product information for the Order No.



3 Installation

Connection to the cooling water circuit

Integrate the heater, water pump, non-return valve, thermostat and T-piece in the cooling water circuit

Cut the water flow hose from the vehicle engine to the vehicle's heat exchanger and insert the non-return valve.
Cut the water return hose from the vehicle's heat exchanger to the vehicle engine and insert the T-piece.
Use water hoses to connect the heater and water pump to the thermostat, the non-return valve and T-piece – as shown in the sketch.


Heating characteristics

Small cooling water circuit

Initially, up to a cooling water temperature of approx. 70 °C, the heater's heat is fed to the vehicle's heat exchanger only – fast heating of the inside of the vehicle.

Large cooling water circuit

If the cooling water temperature continues to rise, the thermostat slowly switches over to the large circuit (full switchover is reached at approx. 75 °C) – heating of the inside of the vehicle and additional engine pre-heating.



Please note!

The thermostat, non-return valve and T-piece must be ordered separately, please refer to the product information for the Order No.

Function of the thermostat

At a cooling water temperature < 70 °C – small cooling water circuit:


- Socket 1 – open (to the heater)
- Socket 2 – open (to the T-piece)
- Socket 3 – closed (to the non-return valve)

At a cooling water temperature > 75 °C – large cooling water circuit:

- Socket 1 – open (to the heater)
- Socket 2 – closed (to the T-piece)
- Socket 3 – open (to the non-return valve)

Please note!

Use the connections item (1), (2) and (3) – as shown in the sketch – to integrate the thermostat in the cooling water circuit.



- 1 Socket, to the heater
- 2 Socket, to the T-piece
- 3 Socket, to the non-return valve

3 Installation

Connection to the cooling water circuit

Integrate the heater, water pump and combination valve with thermostat function in the cooling water circuit

Using the combination valve with 5 connections

If the water flow line and water return line from the vehicle engine to the heat exchanger are laid separately in the engine compartment, the combination valve with 5 connections and an additional T-piece must be used.

Using the combination valve with 6 connections

If the water flow line and water return line from the vehicle engine to the heat exchanger are laid in parallel in the engine compartment, the combination valve with 6 connections (without T-piece) must be used.

Heating characteristic in parking heater mode – small cooling water circuit

Initially, up to a cooling water temperature of approx. 67 °C, the heater's heat is fed to the vehicle's heat exchanger only – fast heating of the inside of the vehicle.

From a cooling water temperature of approx 67 °C, part of the heater's heat is also passed to the vehicle's engine. This causes additional engine pre-heating, without rapid cooling of the "small cooling water circuit" for interior heating.

Heating characteristic in auxiliary heater mode – large cooling water circuit


While the vehicle's engine is running the heat is uniformly distributed between the vehicle's heat exchanger and the vehicle engine – further shortening of the heating up phase and heating of the inside of the vehicle.

Install combination valve with 5 connections

Cut the water flow hose from the vehicle engine to the vehicle's heat exchanger and insert the combination valve. Cut the water return hose from the vehicle's heat exchanger to the vehicle engine and insert the T-piece. Use water hoses to connect the heater and water pump to the combination valve and and T-piece – as shown in the sketch.

Install combination valve with 6 connections

Cut the water flow hose and the water return hose from the vehicle engine to the vehicle's heat exchanger and insert the combination valve. Use water hoses to connect the heater and water pump to the combination valve – as shown in the sketch .





3 Installation

Exhaust system

The complete exhaust system to be installed is included in the scope of supply of the universal installation kit. The exhaust system consists of a flexible exhaust pipe, inner Ø 24 mm, 900 mm long, a flexible exhaust pipe end with end sleeve, inner Ø 24 mm, 300 mm long and an exhaust silencer.

The exhaust system can be shortened to a min. length of 200 mm according to the installation conditions.

The whole exhaust system can be extended up to max.

2 m (see sketch, page 22).

Please refer to the additional parts catalogue for details of parts for extending the exhaust system.

Mounting the exhaust system

Use a bracket included in the universal installation kit (L bracket or Z bracket) to fix the exhaust silencer in a suitable position on the vehicle (see sketch on page 22).

Lay the flexible exhaust pipe from the heater to the exhaust silencer and fasten with pipe clips (tightening torque:

7^{+0.5} Nm), adjust the length if necessary.

If necessary, shorten the exhaust pipe end with end sleeve, push onto the exhaust silencer and fix with a pipe clip (tightening torque: 7^{+0.5} Nm).

If necessary, use pipe clips to fasten the flexible exhaust pipe and the exhaust pipe end in suitable positions in the vehicle.

If necessary, attach spacer rings to the flexible exhaust pipe and to the exhaust pipe end.

- Exhaust pipes must be safely fixed (recommended clearance of 50 cm) to avoid damage from vibrations.
- Lay the exhaust system so that the outflowing exhaust gases are not sucked in as combustion air.
- The mouth of the exhaust pipe must not become clogged with dirt and snow.
- The mouth of the exhaust pipe must not point in the direction of travel.
- Always fix the exhaust silencer to the vehicle.
- Lay the exhaust system so that the exhaust fumes do not flow directly onto heat-sensitive components.



Danger!

Risk of injuries and burns!

Every type of combustion produces high temperatures and toxic exhaust fumes. This is why the exhaust system must be routed according to these installation instructions.

- Do not perform any work on the exhaust system while the heater is working.
- Before working on the exhaust system, switch off the heater first and wait until all the parts have completely cooled down, wear safety gloves if necessary.
- Do not inhale exhaust fumes.

Please note!

- Comply with the regulations and safety instructions for this chapter given on page 4 – 7.
- The exhaust pipe end should be much shorter than the flexible exhaust pipe from the heater to the exhaust silencer.



Caution!

Safety instructions!

The whole exhaust system gets very hot while the heater is running and immediately afterwards. This is why the exhaust system must be routed according to these installation instructions.

- The exhaust pipe must end in the open air.
- The exhaust pipe may not protrude beyond the lateral limits of the vehicle.
- Install the exhaust pipe sloping slightly downwards. If necessary, make a drain hole with approx. Ø 5 mm at the lowest point as a condensation outlet.
- Important functional parts of the vehicle may not be impaired (maintain sufficient clearance).
- Mount the exhaust pipe with sufficient clearance to heat-sensitive parts. Pay particular attention to fuel pipes (made of plastic or metal), electrical cables and brake hoses, etc.!

3 Installation

Combustion air system

Installing the combustion air system

The combustion air must be drawn out of an area which does not become hotter than 25 °C and in which neither spray water or dust / dirt are to be expected.

The flexible combustion air hose included in the universal installation kit (double-walled, sound insulating), inner Ø 20 mm, 760 mm long, must be installed with a hose clip (tightening torque 3^{+0.5} Nm), in order to remove the combustion air from an area, which fulfils the conditions named above.

If necessary, the flexible combustion air hose can be shortened according to the installation conditions.

When shortening the combustion air hose, ensure the cutting edge is clean, small cut-off pieces could block the combustion air fan.

Please note!


Comply with the regulations and safety instructions for this chapter given on page 4 – 7.



Caution!

Safety instructions for the combustion air system

- The combustion air opening must be free at all times.
- Lay the combustion air intake to ensure that exhaust fumes cannot be sucked in as combustion air.
- Arrange the combustion air intake so that it is not directed against the wind blast or airstream.
- The combustion air intake must not become clogged with dirt and snow.
- Install the combustion air intake system sloping slightly downwards. If necessary, make a drain hole approx. Ø 5 mm at the lowest point to drain off condensation.



1 Heater

2 Combustion air hose

3 Flexible exhaust pipe


4 Exhaust silencer

5 Exhaust pipe end with end sleeve


6 Spacer ring

Fix bracket to exhaust silencer

Various options for fixing the L bracket to the exhaust silencer (tightening torque 6 Nm)



Various options for fixing the Z bracket to the exhaust silencer (tightening torque 6 Nm)





3 Installation

Fuel supply

Install the metering pump and pulse damper, lay the fuel pipes and install the fuel tank

The following safety instructions must always be observed when installing the metering pump, the pulse damper, laying the fuel pipes and installing the fuel tank.

Deviations from the instructions stated here are not allowed. Failure to comply can result in malfunctions.



Danger!

Risk of fire, explosion, poisoning and injuries!

Caution when handling fuel.

- Switch off the vehicle engine and the heater before refuelling and before working on the fuel supply.
- Avoid naked flames when handling fuel.
- Do not smoke.
- Do not inhale petrol fumes.
- Avoid any contact with the skin.




Caution!

Safety instructions for laying the fuel pipes!

- Use a sharp knife only to trim the fuel hoses and pipes. Interfaces must not be crushed and must be free of burrs.
- The fuel pipe from the metering pump to the heater should be laid with a continuous rise.
- Fuel pipes must be securely fixed to avoid any damage and / or noise due to vibrations (recommended guideline value: of approx. 50 cm).
- Fuel pipes must be protected against mechanical damage.
- Lay the fuel pipes so that any distortion or shaking of the vehicle, engine movements, etc. do not have a disadvantageous effect on the service life.
- Use hose clips to secure all hose connections in the fuel supply (tightening torque: $1^{+0.2}$ Nm).

- Parts carrying fuel must be protected from interfering heat.
- Never route or fix the fuel pipes to the heater's or vehicle's exhaust system.
When systems cross, always ensure there is a sufficient heat clearance. If necessary, attach heat deflection plates.
- Dripping or evaporating fuel must never be allowed to collect on hot parts or ignite on electric equipment.
- When connecting fuel pipes with a fuel hose, always mount the fuel pipes in a butt joint to prevent any bubbles from forming.



- 1 Correctly laid lines
- 2 Incorrectly laid lines – bubbles form



Caution!

Safety instructions for fuel pipes and fuel tanks in buses and coaches

- In buses and coaches, fuel pipes and fuel tanks must not be routed through the passenger compartment or driver's cab.
- Fuel tanks in buses and coaches must be positioned in such a way that the exits are not in immediate danger if a fire occurs.

Please note!


Comply with the regulations and safety instructions for this chapter given on page 4 – 7.

3 Installation


Fuel supply

Install pulse damper

Insert the metering pump into the rubber holder.
Connect the pulse damper directly to the discharge end of the metering pump using a fuel hose 3.5 x 3 (di = Ø 3.5 mm), approx. 50 mm long.
When installing the pulse damper, please note the direction of flow and installed position.
Secure all connection points with hose clips.



Preferred fuel extraction with tank connection or with adapter



- 1 Tank connection, di = Ø 2 mm, da = Ø 4 mm – installed in the vehicle's own tank fitting
- 2 Adapter, Ø 7.5 / 3.5 mm – connected at the vehicle's own tank fitting at a pipe socket Ø 8 mm used to pass through the intake line (fuel pipe 4 x 1).
- 3 Metering pump
- 4 Fuel filter – required for contaminated fuel only
- 5 Fuel pipe, 4 x 1 (di = Ø 2 mm, transparent)
- 6 Fuel hose, 3.5 x 3 (di = Ø 3.5 mm) approx. 50 mm long
- 7 Elbow, 105°
- 8 Pulse damper

Permissible pipe lengths

Intake side

a = max. 2 m

Pressure side

b = min. 1 m up to max. 6 m



Caution!

Safety instructions for the fuel supply!

The fuel must not be discharged by means of gravity or overpressure in the fuel container.

Please note!


- Items (4) and (7) are not included in the "Universal installation kit" scope of supply. Refer to the product information for the Order No. See additional parts catalogue for Order No.
- Use two hose clips Ø 11 to secure the adapter Ø 7.5 / 3.5 mm, Item (2).



3 Installation

Fuel supply

Fuel extraction using T piece from the fuel return line laid between the vehicle engine to the tank fitting



- 1 Fuel return line from the vehicle's own tank fitting
- 2 Fuel flow line from the vehicle's own tank fitting
- 3 Metering pump
- 4 T-piece
- 5 Fuel filter – required for contaminated fuel only
- 6 Fuel pipe, 4 x 1 (di = Ø 2 mm, transparent)
- 7 Fuel hose, 3.5 x 3 (di = Ø 3.5 mm)
approx. 50 mm long
- 8 Elbow, 105°
- 9 Pulse damper
- 10 from the vehicle engine to the tank fitting

- Always insert the T piece in the fuel return line. Check first that no non-return valves are installed and that the return line from the tank fitting ends just in front of the bottom of the tank.
- Connect the T-piece and the plastic pipe with the relevant fuel hoses and secure with hose clips.
- If the pressure in the fuel pipe is more than 0.2 bar up to max. 4.0 bar, use a pressure reducer (Order No. 22 1000 20 08 00) or a separate tank connection.
- If the pressure in the fuel pipe is over 4.0 bar or if there is a non-return valve in the return pipe (in the tank), a separate tank connection must be used.

Permissible pipe lengths

Intake side

a = max. 2 m

Pressure side

b = min. 1 m up to max. 6 m

Please note!

- Items (4), (5) and (8) are not included in the "universal installation kit" scope of supply.
- Installation of the fuel filter Item (5) requires two adapters Ø 5 / 3.5, Order No. 25 1888 80 01 02.




Caution!

Safety instructions for the fuel supply!

- It is not permitted to extract fuel downstream of the vehicle's own fuel pump.
- If using a T-piece in a plastic pipe, always insert support sleeves in the plastic pipe.

Installation position of the T-piece

Install any T-piece in the same installation positions shown in the diagram.



- 1 Direction of flow – to the fuel tank
- 2 Direction of flow – from the vehicle engine


3 Installation

Fuel supply

Installation position of the metering pump

Always install the metering pump with the delivery side rising upwards.

Any mounting position over 15° is allowed, although a mounting position between 15° and 35° is preferable.



- 1 Installation position within range 0° – 15° is not allowed
- 2 Preferred installation position within range 15° – 35°
- 3 Installation position within range 35° – 90° is allowed

Permissible suction and pressure head of the metering pump

Pressure head from vehicle tank to metering pump:

a = max. 3000 mm

Suction head in pressure-less vehicle tank:


b = max. 1000 mm

Suction head in a vehicle tank in which negative pressure occurs during extraction (valve with 0.03 bar in the tank cap):

b = max. 400 mm

Pressure head from the metering pump to the heater:

c = max. 2000 mm



- 1 Connection at the heater
- 2 Max. fuel level
- 3 Min. fuel level

Please note!

Check tank ventilation.



Caution!

Safety instructions for installing the metering pump!

- Always install the metering pump with the delivery side rising upwards – minimum angle 15°.
- Protect the metering pump and filter from impermissible heating, do not install near to silencers and exhaust pipes.



3 Installation

Fuel supply

Fuel quality for diesel heater

- The heater runs without problems on normal commercial diesel fuel according to DIN EN 590.
During the winter months the diesel fuel is adapted to low temperatures from 0 °C to –20 °C. Problems can therefore only arise if outdoor temperatures are extremely low – which also applies to the vehicle's engine – please refer to the vehicle manufacturer's regulations.
- In special cases and at outdoor temperatures above 0 °C the heater can also be run on heating oil EL according to DIN 51603.
- If the heater is run from a separate tank, please comply with the following rules:
 - If outdoor temperatures over 0 °C:
Use diesel fuel according to DIN EN 590.
 - If outdoor temperatures from 0 °C to –20 °C:
Use winter diesel fuel according to DIN 590.
 - If outdoor temperatures –20 °C to –40 °C:
Use Arctic Diesel or Polar Diesel.

Please note!

- Additions of used oil are **not** allowed!
- After refuelling with winter or cold diesel or the listed blends, the fuel pipes and the metering pump must be filled with the new fuel by letting the heater run for 15 minutes!

Operation with biodiesel

(FAME for diesel engines according to DIN EN 14 214)

The heater is approved for operation with biodiesel up to a temperature of –8 °C (the flowability reduces at temperatures below 0 °C).

Please note!

- If operated with biodiesel (100 % operation and blends) the heating output of the heater reduces.
- A reduced heater life is to be expected if constantly operated with 100 % biodiesel.
- Standard diesel fuel contains up to 20 % biodiesel; this does not have any effect on the life of the heater.

4 Operation and function

Operating instructions

The heater is operated by a control unit. Detailed operating instructions are supplied with the control unit.

Please note!

You will be issued the operating instructions by the installation workshop.

Important instructions for operation

Initial commissioning of the heater

The following points are to be checked by the company installing the heater during initial commissioning.

- Following installation of the heater, the cooling water circuit and the whole fuel supply system must be carefully vented. Comply with the instructions issued by the vehicle manufacturer.
- Open the coolant circuit before the trial run (set the temperature control to "WARM").
- During the heater trial run, all water and fuel connections must be checked for leaks and secure, tight fit.
- If faults occur while the heater is running, use a diagnostic unit to determine and correct the cause of the fault.

Safety checks before starting up the heater


After a lengthy stoppage (summer months), check all components for secure fit (tighten screws where necessary). Carry out a visual check of the fuel system for leaks.

Before switching on

Before switching on or pre-programming heating mode, switch the vehicle's heating control to "WARM" (maximum setting) and the blower to "slow level" (low electricity consumption).
In vehicles with automatic heating, before switching off the ignition, switch the heating control to "MAX" and the required damper position to "OPEN".

Functional description

Switch on parking heater mode


When the heater is switched on, the  symbol appears in the control unit.

Heating mode

The water pump starts up and, following a preset sequence, the combustion air fan, glow plug and metering pump are started. The glow plug is switched off once a stable flame has formed in the combustion chamber.

Depending on the heat requirements, the heater runs at the following levels: Power – High – Low – Off (pause mode). The temperature thresholds for these are permanently programmed in the electronic control box.

The heater starts in "Power" control stage. After the cooling water temperature has reached approx. 75 °C – depending on the selected blower setting – the heater switches to "High" control stage. If the cooling water continues to rise up to 80 °C, the heater switches to "Low" control stage.

- If the heat output achieved in "Low" control stage is insufficient, the cooling water temperature drops to 75 °C – the heater switches back to "High" control stage.
- If the heating output in "Low" control stage is inadequate, the cooling water temperature rises to 85 °C. The heater switches to "Off" control stage (pause mode) – an after-run of 180 seconds follows.
- If the cooling water temperature cools to 75 °C during pause mode, a controlled start occurs in a high control stage.
- During pause mode the water pump continues to run and the On symbol  continues to be displayed in the control unit.



4 Operation and function

Functional description

Heating at high altitudes

When using the heater at high altitudes, please note:

- Heating at altitudes up to 1500 m:
 - Unlimited heating possible.
- Heating at altitudes over 1500 m – 3000 m:
 - The heater can be run for short periods (e.g. driving through a mountain pass or taking a break in your journey).
 - During longer stays, e.g. winter camping, the fuel supply must be adjusted to the altitude.
This can be done by installing an air pressure sensor. The air pressure sensor is included in the altitude kit – Order No. 22 1000 33 22 00.

- The speed of the blower motor is continuously monitored. If the blower motor does not start up or if it is blocked, the heater is automatically switched off.
- * The control box can be unlocked with testing equipment / a control unit. For the procedure and description for testing equipment and control units, see "Installation Instructions Plus – EasyStart/Altitude Kit / Special Functions and Diagnosis"

For operation and fault list, please refer to the enclosed operating instructions or the troubleshooting and repair instructions for the heater.

Please note!

Do not repeat the switching off / on routine more than twice.

Control and safety devices

- If the heater does not ignite within the preset safety time (70 seconds), the start is repeated.
If the heater still does not ignite after another start attempt within the preset safety time, the heater is automatically shut down.
After an impermissible number of failed start attempts, the control box is locked.*
- If the flame goes off by itself during operation, the heater is restarted.
If the heater does not ignite or ignites but goes out again within 10 minutes, a safety lock-out occurs. The safety lock-out can be cancelled by briefly switching off and on again (ignition ON / OFF).
- In the case of overheating (e.g. water shortage, poorly ventilated cooling water circuit), the overheating sensor triggers, the fuel feed is interrupted and the heater is automatically shut down. Once the cause of the overheating has been eliminated, the heater can be re-started by switching off and on again (ignition ON / OFF).
Precondition: the heater has cooled down sufficiently, cooling water temperature < 70 °C.
After an impermissible number of shut-downs on overheating, the control box is locked*.
- If the lower or upper voltage limit is reached, the heater is automatically shut down.
- The heater does not start up if the glow plug is defective or if the electric cable to the metering pump is interrupted.

Emergency shutdown – EMERGENCY OFF

If an emergency shutdown – EMERGENCY OFF – is necessary during operation, proceed as follows:

- Switch the heater off at the control unit or
- remove the fuse or
- disconnect the heater from the battery or
- if necessary activate the battery isolating switch.

5 Electrical system

Heater wiring



Caution!

Safety instructions for wiring the heater!

The heater is to be connected up electrically according to the EMC directives. EMC can be affected if the heater is not connected up correctly. For this reason, comply with the following instructions:

- Ensure that the insulation of electrical cables is not damaged.
Avoid:
chafing, kinking, jamming or exposure to heat.
- Seal any connector chambers of watertight connectors not in use with filler plugs to ensure they are dirt-proof and water-proof.
- Electrical connections and ground connections must be free of corrosion and firmly connected.
- Lubricate connections and ground connections outside the heater interior with contact grease.
- **For Hydronic II-C - 24 volt only.**
The "metering pump" and "water pumps" lead harnesses can be mixed up when connected. Therefore, please note the following characteristics:
"Metering pump" lead harness
 - 6 m long
 - 2 connector housings of the same type
- "Water pump" lead harness
 - 2 m long
 - 2 different connector housings

Please note!

Comply with the following when wiring the heater and the control unit:

- Electrical leads and components must be positioned in the vehicle so that they can function perfectly under normal operating conditions without impairment (e.g. due to heat exposure, moisture, etc.).
- The following cable cross section is to be used between the battery and heater.
This ensures that the max. permissible voltage drop in the cables does not exceed 0.5 V for 12 V rated voltage.
Cable cross-section for a cable length (plus cable + minus cable) up to 6 m = cable cross-section 4² mm.
- If the positive cable is to be connected to the fuse box (e.g. terminal 30), the vehicle's cable from the battery to the fuse box must also be included in the calculation for the total cable length and re-dimensioned if necessary.
- Insulate unused cable ends.

Parts list for circuit diagram, heater and cable harness – 12 Volt / 24 Volt / ADR

-A10	Control box
-B1	Surface sensor
-B2	Control and overheating sensor
-B5	Flame sensor
-M1	Burner motor
-R1	Glow plug
-R2	Heating element, combustion chamber
-XB4	Bush housing, internal heater connections
-XB9/2	Bush housing, water pump
-XB9/3	Bush housing, water pump
-XS1	Connector housing, heater signals
-XS2	Connector housing, heater supply
b	Activation, vehicle fan
n	Generator input D+
o	Input, power take-off NA+
-A30	Fuse holder, 3 pin
-F1	Fuse, heater
-F2	Fuse, control unit
-F3	Fan relay fuse
-K1	Fan relay
-M10	Water pump
-XB1	Bush housing, heater signals
-XB2	Bush housing, heater supply
-XB6	Bush housing, diagnostics tester plug-in connection
-XB7	Relay block
-XB8	Bush housing, metering pump
-XB8/1	Bush housing, metering pump plug-in connection
-XS6	Connector housing, diagnostics tester plug-in connection
-XS8/1	Connector housing, metering pump plug-in connection
-Y1	Fuel metering pump
a	to the heater
c	to the control unit
i	ADR feedback to the control unit
x	Insulate cable and tie back

Connectors and bush housings are shown from the cable inlet side.

Cable colours


RD	red	GR	grey	BK	black
BU	blue	YE	yellow	GN	green
WH	white	VT	violet	BN	brown
OR	orange				



5 Electrical system

Heater circuit diagram – 12 Volt / ADR

X:15 ○ Ign (+)
 X:58 ○ Light (+)
 X:30 ○ Bat (+)
 X:31 ○ Bat (-)




25.2506.00.9601

See page 30 for parts list.

5 Electrical system

Cable harness circuit diagram – 12 Volt / ADR




See page 30 for parts list.



5 Electrical system

Heater circuit diagram – 24 Volt / ADR


X:15 ○ Ign (+)
 X:58 ○ Light (+)
 X:30 ○ Bat (+)
 X:31 ○ Bat (-)



25.2507.00.9601

5 Electrical system

Cable harness circuit diagram – 24 Volt / ADR




See page 30 for parts list.



5 Electrical system

Circuit diagram – EasyStart Timer



22.1000.34.9701

-E3 EasyStart Timer
-B8 Room temperature sensor (optional)
c to the cable harness


Connectors and bush housings are shown from the cable inlet side.

i Note

Further circuit diagrams for the EasyStart Timer are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.

5 Electrical system

Circuit diagram – EasyStart Timer-ADR



22.1000.34.9710

-E3 EasyStart Timer
-B8 Room temperature sensor (optional)
-H3 Button
c to the cable harness
i ADR feedback from the heater

Connectors and bush housings are shown from the cable inlet side.



Note

Further circuit diagrams for the EasyStart Timer are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.




5 Electrical system

Circuit diagram – EasyStart Remote⁺

X:15 ○
Ign (+)

X:58 ○
Light (+)



22 1000 34 9722

-B8 Room temperature sensor
-E5 Stationary unit, EasyStart Remote⁺
-H2 Button
-W2 Antenna
c to the cable harness

Connectors and bush housings are shown from the cable inlet side.



Note


Further circuit diagrams for the EasyStart Remote⁺ are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.

5 Electrical system

Circuit diagram – EasyStart Remote

X:15 ○
Ign (+)

X:58 ○
Light (+)



22.1000.34.9733

-E4 Stationary unit EasyStart Remote
-H2 Button
-W2 Antenna
c to the cable harness

Connectors and bush housings are shown from the cable inlet side.

i Note

Further circuit diagrams for the EasyStart Remote are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.




5 Electrical system

Circuit diagram – EasyStart Select

X:15 ○
Ign (+)

X:58 ○
Light (+)



-XB4



-XS4

22.1000.34.9734

-E2
c

EasyStart Select
to the cable harness

Connectors and bush housings are shown from the cable inlet side.




Note

Further circuit diagrams for the EasyStart Select are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.

5 Electrical system

Circuit diagram – EasyStart Web



22.1000.34.9719

-B10 Room temperature sensor
-E6 EasyStart Web
-H4 Button
c to the cable harness

Connectors and bush housings are shown from the cable inlet side.



Note

Further circuit diagrams for the EasyStart Web are printed in the Installation Instructions Plus, these are available to view and download from the Service Portal.



6 Troubleshooting / maintenance / service

If any faults occur, please check the following items

- If the heater does not start after being switched on:
 - Switch the heater off and on again.
- If the heater still does not start, check whether:
 - Fuel in the tank?
 - The fuses are ok?
 - The electrical cables, connections, terminals, are ok?
 - Anything is clogging the combustion air supply or exhaust system?

Troubleshooting

If, after checking these items, the heater is still faulty or another malfunction occurs in your heater, please contact:

- If factory-installed, your contract workshop / garage.
- If subsequently installed, the workshop / garage which installed the heater.

Please note!

Please note that guarantee claims can expire if the heater is modified by a third party or if non-original parts are installed.

Maintenance instructions

- Switch the heater on once a month for about 10 minutes, even outside the heating period.
- Before the heating period starts, the heater should undergo a trial run. If thick, persistent smoke develops, unusual burning noises or a clear fuel smell occurs or if electric / electronic parts overheat, the heater must be switched off and put out of service by removing the fuse. In this case, the heater should not be started up again until it has been checked by qualified staff who have been trained on Eberspächer heaters.
- Check the openings of the combustion air supply and exhaust system after longer standstill periods, clean if necessary!

Service

Technical Support

If you have any technical questions or problems with the heater, the control unit or the operating software, please contact the following service address:

support-UK@eberspaecher.com

7 Environment

Certification

The high quality of Eberspächer's products is the key to our success. To guarantee this quality, we have organised all work processes in the company along the lines of quality management (QM). Even so, we still pursue a large number of activities for continuous improvement of product quality in order to keep pace with the similarly constantly growing requirements made by our customers. All the steps necessary for quality assurance are stipulated in international standards.

This quality is to be considered in a total sense. It affects products, procedures and customer / supplier relationships. Officially approved public experts assess the system and the corresponding certification company awards a certificate.

Eberspächer Climate Control Systems GmbH has already qualified for the following standards:

**Quality management as per
ISO TS 9001:2015 and IATF 16949:2016**

**Environmental management system as per
ISO 14001:2015**

Disposal

Disposal of materials

Old devices, defect components and packaging material can all be separated and sorted into pure-grade fractions so that all parts can be disposed of as required in an environment-friendly manner recycled where applicable.

Electric motors, control boxes and sensors (e.g. temperature sensors) are deemed to be "electronic scrap".

Dismantling the heater

The heater is dismantled according to the repair stages in the current troubleshooting / repair instructions.

Packaging

The packaging of the heater can be kept in case it has to be sent back.

EU Declaration of Conformity

We herewith declare that the version of the heater placed on the market by us conforms to the applicable provisions of the following EU Directive.

EU Directive 2014/30/EU



The full Declaration of Conformity can be viewed and downloaded from the download centre under www.eberspaecher.com.

UKCA Declaration of Conformity

We herewith declare that the version of the heater placed on the market by us conforms to the applicable provisions of the following UK Directive.

Electromagnetic Compatibility, Statutory Instrument 2016, No. 1091



The full Declaration of Conformity can be viewed and downloaded from the download centre under www.eberspaecher.com.



8 List

List of abbreviations

ADR

European agreement about the international transport of dangerous goods on the road.

EU type-approval

Permit awarded by the Federal Vehicle Office for the production of a heater for installation in motorised vehicles.

EMC directive

Electromagnetic compatibility.

JE-partner

Eberspächer partner.

FAME

Biodiesel fuel to EN 14214.

www.eberspaecher.com

Eberspächer Climate
Control Systems GmbH
Eberspächerstraße 24
73730 Esslingen
Germany
info@eberspaecher.com
www.eberspaecher.com



Eberspächer