



## Parts List

- 1.1 Blower Motor
- 1.2 Glow Pin
- 1.5 Overheating sensor and flame sensor
- 2.1 Electronic Control Unit (ECU)
- 2.2 Fuel Metering Pump
- 5.1 Battery
- 2.7 Main Fuse 20A- 12v
- 2.7.1 Switch Fuse 5A- 12v
- 3.1.17 Mini Controller
- 3.1.18 701 10 103 Timer (Option)
- 3.2.20 801 Modulator

②.7 Fuse Blade Type- main fuse

10A For 24v System  
20A For 12v System

## Colour Codes

- bl - Blue
- rt - Red
- ge - Yellow
- br - Brown
- gr - Green
- ws - White
- sw - Black
- vi - Violet