

Dual Top Service Check

Additional checks when servicing an DualTop



Each time a Dual Top is serviced , it is the opportunity to reduce our risks for a new case in the future by checking the compliance of the application to our Webasto guidelines and standards. **IMPORTANT !!**

So, Please perform the following additional checks when servicing a unit:

1. Check if John Guest adapters are applied
2. Check if air outlet hoses are screwed
3. Check if ventilator is correctly centered after intervention : placing washers to centralize ventilator,

1. Check John Guest Adapter

John Guest Adapters

Always use the John Guest adapters! We encountered various flooded DualTops equipped with less sophisticated “homemade” solutions.

Please always check and if not existing, immediately install John Guest adapters!



9020573 B 10mm tube to pipe connector



9020574 B 15mm zu 10mm tube connector

2. Air hose fastening

Air Ducting

Always secure the outlet hoses with 3 screws for every hose to avoid loosening hoses!

Please always check and if not existing, immediately secure the hoses with 3 screws!



3. Mount air intake adapter

Air intake adapter (Schnecke)

If you encounter problems with blocked burner fans in outside applications the air intake adapter can be a solution. Please apply the adapter in such cases.

Furthermore, we recommend to use the adapter in general.



1314904A
Air intake adapter
Dual Top Ø 60

